

# Posa in opera

—  
Installation process

## Fasi di posa

1. Tracciare delle linee guida per il corretto posizionamento
2. Assicurarsi che la muratura sia il più pulita possibile
3. Applicazione di normale colla da cappotto sul profilo
4. Posizionamento della cornice.
5. Applicare del nastro di carta nelle due parti terminali da giuntare.
6. Consigliamo di inserire degli spessori tipo ferma vetri di plastica da mm 2/3, con funzione di distanziali, e applicare il sigillante tipo MS-SPECIAL.
7. Unire i due elementi e livellare l'eccedenza su tutto il perimetro della cornice.
8. Rimuovere il nastro di carta e successivamente tinteggiare le decorazioni con qualsiasi tipologia di pittura muraria.

## Installation steps

1. Trace the guidelines for an exact positioning.
2. Make sure the wall surface is clean and clear.
3. Apply Insulating glue on the back of the moulding.
4. Position the moulding on the wall.
5. Apply adhesive tape on the two borders which have to be joint
6. We recommend you to use some plastic spacers (2/3 mm thick) between the joints and apply the MS-Special sealant.
7. Join the two elements and eliminate the excess of sealant alongside the cornice perimeter borders.
8. Remove the adhesive tape from the borders. Now you can paint the moulding with any type of wall finishing paint

Per gli elementi di dimensioni più importanti vedere  
pagina 32

For large size decorative elements installation,  
go to page 32

